

RVi

RU



**RVi-IPN32/8-PRO**





	<b>RVi-IPN32/8-PRO</b>
	.264
	32
	1 HDMI, 1 VGA, 1 BNC
( )	1920×1080, 1280×1024, 1280×720, 1024×768, 800×600
/	1 (BNC) / 1 (BNC)
	G.711A
\	16/6
	75 10
( )	5MP(2560x1920) / 3MP(2048x1536) / 1080P(1920x1080) / 720P(1280x720) / D1 (704.576/704x480)
	400 / (1080p), 400 / (720p)
/	, , , 30 / 300
HDD	SATA3 4
HDD	8 HDD SATA+4 HDD eSATA
USB	4 .(2 )
RS485	PTZ
RS232	, , ,
	32 SATA + 16 eSATA
	, / ( , ),
	1 Gbit Ethernet
	HTTP, IPv4/IPv6, TCP/IP, UPNP, RTSP, UDP, SMTP, NTP, DHCP, DNS, PPPOE, DDNS, FTP, IP
C	web- (IE, Google chrome, Firefox Mozilla,Opera) RVi-PSS Windows XP Windows 7, MAC OS. : S Symbian, S Windows mobile, S Android, S Blackberry, i S.
	IP- RVi
	20
	/
	22 18 , 6
	-10...+55 °C
	100-240 AC, 40 HDD
	440x460x89 ( )
	6 HDD


- SATA 1 .
- USB 8 .
- CD ( 1 .
- 19" 1 .
- 1 .



1.

1

1		.
2		( / ) .
3		.
4	0-9	.
5		USB
6	REC	
7	Fn	
8	ESC	



**HDD**

SATA


HDD

HDD.



HDD

SATA



**Enter**



- : admin. : admin. ( , )
- : 888888. : 888888. ( , )
- : default. : default ( , )

USB-



( ).


:

WEB-

web- NVR  
 ping \*\*\*.\*\*\*.\*\*\*.\*\*\*(\* IP NVR)  
 TTL 255.  
 IE NVR.  
 : IP 192.168.1.108.  
 http://192.168.1.108 Internet Explorer.

« ».

ActiveX,



»,

« ».

«

».

IP


«  
DVR.

WEB

admin

admin.

« ».



WEB


4

:



WEB

:



:

CD

<http://www.rvi-cctv.ru/>



( , . . ) , ,

69. 5 15150-

NVR 1 15150-69.

- , , - 36



; ; ;

-

:

Web

Four horizontal lines for input

:

\_\_\_\_\_



BY

# RVi- IPN32/8-PRO







	<b>RVi-IPN32/8-PRO</b>
	.264
	32
	1 HDMI, 1 VGA, 1 BNC
( )	1920×1080, 1280×1024, 1280×720, 1024×768, 800×600
/	1 (BNC) / 1 (BNC)
	G.711u
/	16/6
	75 10
( )	5MP(2560x1920) / 3MP(2048x1536) / 1080P(1920x1080) / 720P(1280x720) / D1 (704.576/704x480)
	400 / (1080p), 400 / (720p)
	, , ,
/	30 / 300
HDD	SATA3 4
HDD	8 HDD SATA+4 HDD eSATA
USB	4 (2 )
RS485	PTZ
RS232	
,	32 SATA + 16 eSATA
	, / ( , ),
	1 Gbit Ethernet
	HTTP, IPv4/IPv6, TCP/IP, UPNP, RTSP, UDP, SMTP, NTP, DHCP, DNS, PPPOE, DDNS, FTP, IP i e
	web- (IE, Google chrome, Firefox Mozilla,Opera) C RVi PSS Windows XP Windows 7, MAC OS. : S Symbian, S Windows mobile, S Android, S Blackberry, i S.
	20
	/
	22 18 , 6
	-10...+55 °C
	100-240 AC, 40 HDD
	440x460x89 ( )
	6 HDD


: , ,  
 SATA 1 .  
 USB 8 .  
 CD ( 1 .  
 19 " , ) 1 .  
 1 .



1.

1

1		.
2		( / ) .
3		.
4	0-9	.
5		USB
6	REC	
7	Fn	
8	ESC	



### HDD

SATA


HDD

HDD.




HDD

SATA



DVR?

Enter




( : 888888. : 888888. ( : admin. : admin. )  
 : default. : default ( )  
 USB-  
 ( )

web- ping \*\*\*.\*\*\*.\*\*\*.\*\*\*(\* IP TTL, 192.168.1.108, " " .

WEB-DVR . DVR. 255. IP Internet Explorer. webrec.cab .

ActiveX,



\_\_\_\_\_ :

\_\_\_\_\_ :

192.168.1.108

(https:)

“ ”

“ ”

IP

DVR.

WEB

admin admin. " "



WEB


5

: , , ,



WEB

:



( , . . ) , , , ,

1 DVR 5 15150-69.

15150-69.

-

- 36

WEB

:



**KZ**

# RVi- IPN32/8-PRO







	<b>RVi-IPN32/8-PRO</b>
	.264
	32
	1HDMI, 1 VGA, 1 BNC
( )	1920×1080, 1280×1024, 1280×720, 1024×768, 800×600
/	1 (BNC) / 1 (BNC)
	G.711u
/	16/6
	10 75
( )	5MP(2560x1920) / 3MP(2048x1536) / 1080P(1920x1080) / 720P(1280x720) / D1 (704x576)
	400 / (1080p), 400 / (720p)
/	, , ,
	30 / 300
HDD	SATA3 4
HDD	8 HDD + eSaTa
USB	4 ( ) 2)
RS485	PTZ
RS232	
	, 32 SATA + 16 eSATA
	, / ( , ),
	1 Gbit Ethernet
	HTTP, IPv4/IPv6, TCP/IP, UPNP, RTSP, UDP, SMTP, NTP, DHCP, DNS, PPPOE, DDNS, FTP, IP
	web- (IE, Google chrome, Firefox Mozilla,Opera) Windows XP Windows 7, MAC OS RVi PSS : S Symbian, S Windows mobile, S Android, S Blackberry, i S.
	20
	/
	22 18 , 6
	-10...+55 °C
	100-240 AC, 40 , HDD
	440x460x89 ( )
	6 , HDD


- SATA 1 .
- USB 8 .
- USB 1 .
- CD ( 1 .
- 19" ) 1 .
- 19" 1 .



1

1

1		
2		( / )
3		
4	0-9	
5		USB
6	REC	
7	Fn	
8	ESC	



## HDD


SATA

HDD

HDD




HDD , SATA



NVR?	NVR ?

Enter



...	

- : admin. : admin. ( , )
- : 888888. : 888888. ( , )
- : default. : default ( )

USB -

( )

123

:

, -




«RVi»	

(https:)	(https:)
...	...

DVR , « IP - . « »

WEB admin admin. « »





WEB 5 : , , ,






WEB





( ,

,

.)  
15150-69 5

.

15150-69

1

NVR

.,

36 .

-

:



;  
, , ;  
;

:

Web

\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

:

\_\_\_\_\_